



B117101 Bathtub Installation Manual



INSTALLATION DIMENSION

Unit: mm



HELPFUL TOOLS

Wrench



5.0mm Hex key



Pencil




Tape Measure



Silicone Sealant




Spirit Level




Safety glasses



Mounting accessories



Towel rack



Pop-up drain



Waste pipe

POINTS FOR ATTENTION BEFORE INSTALLATION

1. Please read the instruction carefully before beginning to install.
2. Please follow steps in the instruction to install this product or may result in costly mistake. Bravat shall not be responsible for any loss from that mistake.
3. Professional help is required for installation of this product.

Inspection


- (1) Check and ensure all switch and accessories are in good condition.
- (2) Check and ensure bathtub surface is free of hit and damage.
- (3) Check and ensure pipe connection is firm and compact.

Attention points at Installation

- (1) To facilitate maintenance and clean, we recommend to install bathtub on
- (2) DONT'T take bathtub out of package for installation until wall and floor preparation finished
- (3) DONT'T remove the protective tape and film of bathtub during installation
- (4) NO bulbs and open fires are allowed to place in bathtub during installation
- (5) NO stuff like sand, cement or other sundries are allowed to place in bathtub as that may likely damage bathtub surface.
- (6) NO solvent like paint or glue are allowed to contact with bathtub.


INSTALLATION INFOREMATION

1




1. Place the bathtub in the installation position.
Note: When the bathtub is unpacked, it should be handled lightly.

2




2.The bathtub is rolled over on the floor with soft sheet material to prevent the bathtub from being damaged.

3




3.Install dewaterer and drain pipe according to schematic diagram.Make sure the pipe is well connected, and then insert the drainage hoseFloor drain.


4



注意：安装完成后须放少量水
检查，管道是否有漏水。



4.Fix the bathtub and install it.
Note: After installation, a small amount of water should be put in to check whether the pipeline is leaking.



MAINTENANCE

1. Suggest to clean bathtub immediately after drainage complete, as soap, body fat and dirt are easy to be removed at the time before bathtub dry.
 2. Suggest to clean bathtub frequently if using in high hard water area, as high calcium content in water would leave yellow spot after dirt attaching on bathtub surface.
 3. Please use soft cloth with neutral cleaner or soap to clean bathtub, and then wipe its surface to dry.
 4. No hard stuff for abrasive stuff like cleaning powder are allowed to clean bathtub, as that would corrode, scratch and dull bathtub surface.
 5. The Iris tub can resist the erosion of most commonly used household chemicals, but it should still avoid contact with strong organic solvents such as paint and paint cleaners such as chloroform and acetone. If they are in contact with the surface of the bathtub, they may cause the surface to soften, melt or crack.
 6. Do not place flaming cigarette on bath or it would burn bathtub surface.
 7. NO bulbs and open fires are allowed to place in bathtub lest bathtub surface is damaged.
- Suggestion to remove scratch:
- (1) If there is a slight scratch or scratch on the surface of the bathtub, scrub it directly with 600# sandpaper or scrub with a scouring pad of abrasive nature.
 - (2) If it is a deep scratch, you can use the **3000 #sandpaper to remove the scratches**, and then use the above method to obtain a flat surface.

latest product information, following the sustainable development strategy of the Company, to improve continually the product's specification, performance etc., subject to change without notice.
(The Company reserves the right to interpret)

Attention: If the product is different from the drawing, please take the object as right.